

Instant Pot

HOW TO DO WATER TEST

WATER TEST

A water test for your pressure cooker is important for 2 reasons:

- helps you get comfortable with your pressure cooker
- ensures your instant pot is working correctly

STEPS OF WATER TEST

- Pour 3 cups of water into your inner pot of your instant pot.
- Put the lid on your instant pot and turn your valve to sealed.
- Set to high pressure for 3 minutes. You do this by hitting cook time or manual button and then plus or minus until the screens reads "3."
- Once pressure is reached, the instant pot will begin to count down from 3 minutes to 0.
- Once the time is done, the Instant Pot will beep and will turn to the "keep warm" function.
- To turn your instant pot off, hit the off button and your pot will read "off."
- Let pressure release and then remove lid and dump out water.
- Start cooking!